

MAINTENANCE SCHEDULE PICKLEBALL SYSTEMS

The following procedures should be performed not less than one time per year to ensure the proper operation of the pickleball system.

1. Check all set screws, nuts and bolts on the unit to ensure that none have worked loose.
2. Floor sleeves should be kept clean of debris that may prevent insertion of post.
3. Floor covers should be checked for proper operation to ensure that they open and close correctly. Broken or damaged covers should be immediately replaced to prevent injuries.
4. Check for any tears in the net. If tears are present, patch or repair immediately to prevent further damage.
5. Check for abnormal wear (i.e. fraying) in the net cables or top cable. Should severe wear be detected, discontinue use immediately and contact your dealer or sales representative.



LIMITED WARRANTY

DRAPER PICKLEBALL EQUIPMENT

All pickleball posts are warranted to the end user for a period of one (1) year from date of shipment. All post collars and associated hardware are warranted for a period of one (1) year from date of shipment. All other equipment including nets, sleeves, floor cover plates, and related accessories are warranted to the end user for a period of one (1) year from date of substantial completion and acceptance. In the event that any component fails under normal use and conditions, that component will be replaced or repaired at no cost for materials. Routine maintenance and adjustment are excluded.

Misuse or abuse from vandalism, improper installation or improper maintenance is not covered under this warranty. Damages due to extreme weather conditions such as floods, tornadoes, or other Acts of God are also expressly not covered under this warranty.

THIS WARRANTY DOES NOT COVER:

1. Dissatisfaction due to improper installation or maintenance or dissatisfaction due to deviation from printed installation and maintenance instructions.
2. Damage in use due to tears, punctures, burns, scuffs, accidents emanating from lack of, or improper operation in conjunction with, adjacent equipment, or any intentional misuse of the product or vandalism.
3. Liability for consequential, incidental, special, or any other damages, no matter what the cause.

EXPIRATION DATE: One (1) year from date of substantial completion of job and acceptance by the owner.