



For use with these part numbers:

383280	383489
383313	383555


### Inventory

2' (61cm)	0
3' (91cm)	2
3½' (107cm)	2
4' (122cm)	0
5' (162cm)	2
6' (183cm)	6
Stiffener	8
	4



**Before assembling StageScreen:**

- Spread the tarp (included)
- Lay the viewing surface facedown on the tarp
- Assemble the frame on top of the screen surface
- Frame sections should be arranged so that:
  - A. Viewing surface attachment posts are on the outside of the frame
  - B. Guide pins should point CLOCKWISE
  - C. Rivcups should face UPWARD
- Red dots above indicate recommended attachment points for flying or wall bracket.



**Caution:**



Beware of Pinch Points