



411 S. Pearl St., Spiceland, IN 47385 USA ■ 765-987-7999
www.draperinc.com ■ fax 765-987-7142

BASIC OPERATION INSTRUCTION FOR WALK-DRAW GYM DIVIDERS

Walk-Draw Gym Divider Curtains are operated by manually pulling the curtain along the track. Follow the below procedures for operating the Walk Draw Divider Curtain:

1. Pull downward with on the leading edge of the curtain with a small amount of force as you walk and draw the curtain. Pulling outward, instead of downward, may cause the carrier to drag or become jammed making the curtain much more difficult to operate.
2. If curtain configuration includes a curve, you will need to feed the curtain through the curve in small section of 2 to 3 feet at a time.
3. When not in use, curtain should be stored at end(s) of track and secured if curtain includes an optional tie-back. Curtain stack dimension is approximately 1-1/8" per linear foot.
4. Never hang or swing from curtain.

If satisfactory performance of the curtain operation cannot be obtained by following the steps above, contact your dealer or sales representative for immediate assistance.

MAINTENANCE SCHEDULE FOR WALK-DRAW GYM DIVIDERS

The following procedures should be performed not less than one time per year to insure continued proper operation of the gym divider.

1. Check all set screws, nuts and bolts on the track and beam clamp assemblies to insure that none have worked loose.
2. Insure that the track splices are secure.
3. Check for any tears in the curtain. If tears are present, patch immediately to prevent further damage.
4. Check for abnormal wear in the trolley assemblies. Should severe wear be detected, discontinue use of the gym divider immediately and contact your dealer or sales representative.
6. Examine all "S" hooks to make sure they are closed.
5. Clean curtain with mild detergent and water or any off-the-shelf vinyl cleaner.



411 S. Pearl St., Spiceland, IN 47385 USA ■ 765-987-7999
www.draperinc.com ■ fax 765-987-7142

LIMITED WARRANTY DRAPER WALK-DRAW

All Walk Draw Gym Divider Curtains are warranted to the end user for a period of one (1) year from date of substantial completion and acceptance or eighteen (18) months after date of shipment whichever comes first. In the event that any curtain component fails under normal use and conditions, that component will be replaced or repaired. Routine maintenance and adjustment excluded.

Misuse or abuse from vandalism, improper installation or improper maintenance is not covered under this warranty. Damages due to extreme weather conditions such as floods, tornadoes or other Acts of God are also expressly not covered under this warranty.

THIS WARRANTY DOES NOT COVER:

1. Dissatisfaction due to improper installation or maintenance or dissatisfaction due to deviation from printed installation and maintenance instructions.
2. Damage in use due to tears, punctures, burns, scuffs, accidents emanating from lack of, or improper operation in conjunction with adjacent equipment or any intentional misuse of the product or vandalism.
3. Liability for consequential, incidental, special or any other damages, no matter what the cause.

DATE APPLIED: One (1) year from date of substantial completion of job and acceptance by the owner or eighteen (18) months after date of shipment, whichever comes first.

DRAPER, INC.