

Repair Instructions

StageScreen Projection Screen Tab Replacement by Draper

Caution

- ① Read instructions through completely before proceeding; retain for future reference.
- ② Handle viewing surface with care; do not allow it to come in contact with sharp or dirty objects and place it on a clean surface before beginning work.
- ③ Tools required: None. Time required: A few seconds per tab.

- ① Remove replacement pull tab from repair kit (see Fig. 1).



Figure 1

DRAPER®

411 S. Pearl St., Spiceland, IN 47385 USA ■ 765-987-7999
www.draperinc.com ■ fax 765-987-7142
Copyright © 2009 Draper Inc. Form StageScreenTabReplacement_Inst09 Printed in U.S.A.

- ② Insert new Pull Tab through Bungee loop on screen (see Fig. 2).



Figure 2

- ③ Loop the Pull Tab through itself and pull taut (see Fig. 3).




Figure 3

If you encounter any difficulties completing this repair, call your dealer or Draper, Inc. in Spiceland, Indiana, 765-987-7999, or fax 765-987-7142.

Repair Instructions

StageScreen Projection Screen Tab Replacement by Draper

Caution

- ① Read instructions through completely before proceeding; retain for future reference.
- ② Handle viewing surface with care; do not allow it to come in contact with sharp or dirty objects and place it on a clean surface before beginning work.
- ③ Tools required: None. Time required: A few seconds per tab.

- ① Remove replacement pull tab from repair kit (see Fig. 1).



Figure 1

DRAPER®

411 S. Pearl St., Spiceland, IN 47385 USA ■ 765-987-7999
www.draperinc.com ■ fax 765-987-7142
Copyright © 2009 Draper Inc. Form StageScreenTabReplacement_Inst09 Printed in U.S.A.

- ② Insert new Pull Tab through Bungee on screen (see Fig. 2).



Figure 2

- ③ Loop the Pull Tab through itself and pull taut (see Fig. 3).




Figure 3

If you encounter any difficulties completing this repair, call your dealer or Draper, Inc. in Spiceland, Indiana, 765-987-7999, or fax 765-987-7142.