

# LVC-S with Locking Cover Plate

Part # 121232

## Overview

The LVC-S with Locking Cover Plate is a 3-button (Up, Stop, Down) wall switch which controls an LVC-IV. The buttons are square. The 2 ¾" x 4 ½" cover plate is plastic, and finished white. The locking cover plate is metal, and provided with a lock and key. LVC-S fits a single-gang box. Installer supplied wire leads (18-24 Gauge). There are screw terminals on the back for Down, Common, and Up.



## Uses

Up, Down and Stop control of an LVC-IV (low-voltage control module) via wall switch.

## Compatibility

The LVC-S can be used with the LVC-IV. Other controls may be connected to the LVC-IV simultaneously:

	NAME	DESCRIPTION	PART NO.
<b>COMPATIBLE COMPONENTS:</b>	<b>LVC-S</b>	Low-Voltage Wall Switch.	121225
	More than one LVC-S can control a single LVC-IV	Low-Voltage Wall Switch w/ Locking Cover	121232
	<b>WRT / R</b>	Radio Frequency Remote Control	Antenna Built-In
	<b>IRT / R</b>	Infrared Remote Control Package	Connects to IR Port
	<b>SP-KSM</b>	3-position Momentary Key Switch (Please Note: 'Stop' won't work).	121022
	<b>Auxiliary Control</b>	Control systems employing "dry" contacts.	By Others
<b>CONTACTS:</b>	Three individual Single Pole, Single Throw contacts (On/Off). Momentary action. Latching contacts are part of the LVC-IV.		
<b>RATING:</b>	10V 25mA		

